

# **MS-PDU User Manual**

## Contents

<b>1. MS-PDU Summary .....</b>	<b>3</b>
<b>2. Main functions.....</b>	<b>3</b>
<b>2.1 Monitor.....</b>	<b>3</b>
<b>2.2 Control.....</b>	<b>3</b>
<b>2.3 Keep the former state of outlets after reset</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>2.4 Self-defined alarm .....</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>2.5 System default alarm .....</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>2.6 Alarm methods .....</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>2.7 User management.....</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>2.8 Access method .....</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>3. Application.....</b>	<b>FOUT! BLADWIJZER NIET GEDEFINIEERD.</b>
<b>4. Product structure diagram .....</b>	<b>4</b>
<b>5. Mounting method.....</b>	<b>5</b>
<b>6. Software instruction: .....</b>	<b>5</b>
<b>6.1 Software summary.....</b>	<b>5</b>
<b>6.2 Access methods .....</b>	<b>5</b>
<b>6.2.1 Web access.....</b>	<b>5</b>
<b>6.2.2 SNMP Access.....</b>	<b>10</b>
<b>6.2.3 Serial access.....</b>	<b>FOUT!</b>
<b>BLADWIJZER NIET GEDEFINIEERD.</b>	
<b>7. Technical parameters.....</b>	<b>FOUT!</b>
<b>BLADWIJZER NIET GEDEFINIEERD.</b>	
<b>8. Quality Warranty.....</b>	<b>14</b>

## MS-PDU User Manual

### 1. MS-PDU Summary:

MS-PDU is the latest scientific achievement of CLEVER after many years of dedicated research. On the trend of future power distribution management technology development, combining the technology requirement of the modern data center application environment, adopting key technology with fully independent intellectual property, the product is designed in combination of network communication, power distribution and network management.

### 2. Main functions

- 2.1 Monitor: total load current, on/off status of each outlet, temperature and humidity
- 2.2 Control: Switch on/off each outlet, set the delay of outlets sequential switching
- 2.3 Keep the former state of outlets after reset.
- 2.4 Self-defined alarm: set the threshold of total load current, temperature and humidity.
- 2.5 System default alarm: when threshold of total load current is exceeded; when threshold of temperature and humidity is exceeded.
- 2.6 Alarm methods: buzzer alarm; red words alerts on web interface; Email alarm; SNMP trap alarm.
- 2.7 User management: user name and password configurable.
- 2.8 Access method: Web based, access via IE; SNMP (v1); Serial access via command line control.

### 3. Application

- 3.1 MS-PDU is applicable to server racks, network racks.
- 3.2 Outlet types and numbers are customized according to specific requirement.
- 3.3 MS-PDU is applicable to 110VAC/32A(16A), 220VAC/32A(16A), 380VAC/32A(16A)

#### 4. Product structure diagram



1. Mounting brackets
2. Wire terminal connection box
3. LED display
4. NET: Ethernet port
5. SER: serial port
6. T/H: temperature & humidity sensor port
7. RUN: operation state indicator
8. STATUS: alarm indicator
9. RESET: reset button
10. BUTTON: selection button
- 11: outlets indicators
- 12: C14 plug locker
- 13: outlets/sockets
- 14; Mounting brackets

→14

## 5. Mounting method

Horizontal or Vertical installation.

## 6. Software instruction

### 6.1 Software summary

MS-PDU is widely applied to the data centers of industries like network communication, telecom, electric power, finance, insurance, aerospace, transportation, information processing, education, medical, E-government etc.

### 6.2 Access methods

MS-PDU can be accessed via Web (support Internet Explorer, Google Chrome, Firefox), SNMP v1 and serial.


#### 6.2.1 Web access

#### How to access the Web?

1. Connect one MS-PDU to the PC directly with the patch cable provided.
2. Check the IP of the PC, make sure it's in the same network segment of the IP of MS-PDU (The factory default IP is 192.168.1.161).

For example: change the IP of the PC to be 192.168.1.X (X can be 0 to 255 except 161)

3. Input the IP of the MS-PDU into the web browser and enter, the login window will pop up. The default User name is niveo and Password is niveo. Main interface as below.



Main interface includes 3 parts: company logo & product name, Device Manager and Server Settings.

Device Manager has 3 sub menus, see below.



Device State: click it to the main interface displaying the on/off state of outlets and the state of temperature and humidity.

Threshold Settings: to set the threshold of load ampere, temperature and humidity. See below.

Item	Output Name	State (A)	Min (A)	Max (A)	Save
1	Output1	0	--	--	Save
2	Output2	0	--	--	Save
3	Output3	0	--	--	Save
4	Output4	0	--	--	Save
5	Output5	0	--	--	Save
6	Output6	0	--	--	Save
7	Output7	0	--	--	Save
8	Output8	0	--	--	Save

Name	State	Min (A)	Max (A)	Save
Input	0	0	25.5	Save

Item	Output Name	State	Min	Max	Save
1	Temperature Sensor1	0	0	99	Save

Device Settings: see below

Device Name: set the name of PDU (name length 1-16 digits)

Output power on delay: set the interval of outlets sequential switching on (1-255s).

Output power off delay: set the interval of outlets sequential switching off (1-255s).

Web server port: fill in the port and save (1-65535).

Service Settings: see below

User Settings: set or modify the user name and password (Max. 16 digits)

The screenshot shows the MS-PDU web interface in a browser window. The address bar displays '192.168.1.163/home.html'. The page has a blue header with the 'niveo' logo and 'MS-PDU' text, and 'Version:1.32' on the right. A left sidebar contains two main sections: 'Device Manager' with links for 'Device State', 'Threshold Settings', and 'Device Settings'; and 'Service Settings' with links for 'User Settings', 'Network', 'SNMP', 'E-mail Alarm Settings', and 'Restart'. The 'User Settings' section is active, showing a 'User Name' field with the value 'clever', and 'Password' and 'Confirm Password' fields, each with six asterisks. A 'Save' button is located below the password fields.

Network: System IP: 192.168.1.163 (factory default IP)

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.1.1

DNS: default as 202.96.128.86. Please fill in the right DNS in order to make the email alert.

**Note: a restart of the software is necessary after a modification of the network settings.**

The screenshot shows the MS-PDU web interface with the 'Network Settings' section active. The left sidebar is identical to the previous screenshot. The 'Network Settings' section contains four input fields: 'System IP' with the value '192.168.1.163', 'Subnet Mask' with '255.255.255.0', 'Default Gateway' with '192.168.1.1', and 'DNS' with '202.96.128.86'. A 'Save' button is positioned below the 'System IP' field.



SNMP: see below (support SNMP v1)

The default get community is “public” and set community is “private”. User can modify according to the specific application.

Fill in the trap address of SNMP management platform, trap alarm will be sent automatically. There are 2 Trap addresses.


**Note: a software restart is necessary after a setting of SNMP.**

Email Alarm Settings: see below

Set the SMTP including SMTP account, password, SMTP server and port and save.

Click Testing and fill in the testing email address. If the test email is received, the setting is successful.

Restart: see below



Select Activity: to restart the software or restore to factory default settings.

### 6.2.2 SNMP Access

The software supports SNMP v1. A MIB file is provided with an enterprise number.

OID table as below.

Item	OID	Description	Mode
Device Name	1.3.6.1.4.1.30966.10.2.1.1	Name of the device	Read/Write
Device Type	1.3.6.1.4.1.30966.10.2.1.2	Type of the device	Read/Write
Output Num	1.3.6.1.4.1.30966.10.2.1.3	Number of outlets	Read
Input Voltage	1.3.6.1.4.1.30966.10.2.2.1	Input voltage	Read
Input Current	1.3.6.1.4.1.30966.10.2.2.2	Input ampere	Read
Output Current1	1.3.6.1.4.1.30966.10.2.3.1	Ampere of outlet No.1	Read
Output Current2	1.3.6.1.4.1.30966.10.2.3.2	Ampere of outlet No.2	Read
Output Current3	1.3.6.1.4.1.30966.10.2.3.3	Ampere of outlet No.3	Read
Output Current4	1.3.6.1.4.1.30966.10.2.3.4	Ampere of outlet No.4	Read
Output Current5	1.3.6.1.4.1.30966.10.2.3.5	Ampere of outlet No.5	Read

Output Current6	1.3.6.1.4.1.30966.10.2.3.6	Ampere of outlet No.6	Read
Output Current7	1.3.6.1.4.1.30966.10.2.3.7	Ampere of outlet No.7	Read
Output Current8	1.3.6.1.4.1.30966.10.2.3.8	Ampere of outlet No.8	Read
Output Current9	1.3.6.1.4.1.30966.10.2.3.9	Ampere of outlet No.9	Read
Output Current10	1.3.6.1.4.1.30966.10.2.3.10	Ampere of outlet No.10	Read
Output Current11	1.3.6.1.4.1.30966.10.2.3.11	Ampere of outlet No.11	Read
Output Current12	1.3.6.1.4.1.30966.10.2.3.12	Ampere of outlet No.12	Read
Output Current13	1.3.6.1.4.1.30966.10.2.3.13	Ampere of outlet No.13	Read
Output Current14	1.3.6.1.4.1.30966.10.2.3.14	Ampere of outlet No.14	Read
Output Current15	1.3.6.1.4.1.30966.10.2.3.15	Ampere of outlet No.15	Read
Output Current16	1.3.6.1.4.1.30966.10.2.3.16	Ampere of outlet No.16	Read
Output Current17	1.3.6.1.4.1.30966.10.2.3.17	Ampere of outlet No.17	Read
Output Current18	1.3.6.1.4.1.30966.10.2.3.18	Ampere of outlet No.18	Read
Output Current19	1.3.6.1.4.1.30966.10.2.3.19	Ampere of outlet No.19	Read
Output Current20	1.3.6.1.4.1.30966.10.2.3.20	Ampere of outlet No.20	Read
Output Current21	1.3.6.1.4.1.30966.10.2.3.21	Ampere of outlet No.21	Read
Output Current22	1.3.6.1.4.1.30966.10.2.3.22	Ampere of outlet No.22	Read
Output Current23	1.3.6.1.4.1.30966.10.2.3.23	Ampere of outlet No.23	Read
Output Current24	1.3.6.1.4.1.30966.10.2.3.24	Ampere of outlet No.24	Read
Switch1	1.3.6.1.4.1.30966.10.2.4.1	On/off state of outlet No.1	Read/Write
Switch2	1.3.6.1.4.1.30966.10.2.4.2	On/off state of outlet No.2	Read/Write
Switch3	1.3.6.1.4.1.30966.10.2.4.3	On/off state of outlet No.3	Read/Write
Switch4	1.3.6.1.4.1.30966.10.2.4.4	On/off state of outlet No.4	Read/Write
Switch5	1.3.6.1.4.1.30966.10.2.4.5	On/off state of outlet No.5	Read/Write
Switch6	1.3.6.1.4.1.30966.10.2.4.6	On/off state of outlet No.6	Read/Write
Switch7	1.3.6.1.4.1.30966.10.2.4.7	On/off state of outlet No.7	Read/Write
Switch8	1.3.6.1.4.1.30966.10.2.4.8	On/off state of outlet No.8	Read/Write
Switch9	1.3.6.1.4.1.30966.10.2.4.9	On/off state of outlet No.9	Read/Write
Switch10	1.3.6.1.4.1.30966.10.2.4.10	On/off state of outlet No.10	Read/Write

Switch11	1.3.6.1.4.1.30966.10.2.4.11	On/off state of outlet No.11	Read/Write
Switch12	1.3.6.1.4.1.30966.10.2.4.12	On/off state of outlet No.12	Read/Write
Switch13	1.3.6.1.4.1.30966.10.2.4.13	On/off state of outlet No.13	Read/Write
Switch14	1.3.6.1.4.1.30966.10.2.4.14	On/off state of outlet No.14	Read/Write
Switch15	1.3.6.1.4.1.30966.10.2.4.15	On/off state of outlet No.15	Read/Write
Switch16	1.3.6.1.4.1.30966.10.2.4.16	On/off state of outlet No.16	Read/Write
Switch17	1.3.6.1.4.1.30966.10.2.4.17	On/off state of outlet No.17	Read/Write
Switch18	1.3.6.1.4.1.30966.10.2.4.18	On/off state of outlet No.18	Read/Write
Switch19	1.3.6.1.4.1.30966.10.2.4.19	On/off state of outlet No.19	Read/Write
Switch20	1.3.6.1.4.1.30966.10.2.4.20	On/off state of outlet No.20	Read/Write
Switch21	1.3.6.1.4.1.30966.10.2.4.21	On/off state of outlet No.21	Read/Write
Switch22	1.3.6.1.4.1.30966.10.2.4.22	On/off state of outlet No.22	Read/Write
Switch23	1.3.6.1.4.1.30966.10.2.4.23	On/off state of outlet No.23	Read/Write
Switch24	1.3.6.1.4.1.30966.10.2.4.24	On/off state of outlet No.24	Read/Write

### 6.2.3 Serial access

Baud rate is 9600.

There are 5 commands: OUTPUT, INPUT, SWITCH, RESET and REBOOT.

OUTPUT command: OUTPUT X

For example: send command OUTPUT 1, get output 1 current: X A.

INPUT command: INPUT X (1 is voltage, 2 is current)

For example: send command INPUT 1, get total voltage: X V

send command INPUT 2, get total current: X A

SWITCH command: SWITCH X

For example: send command SWITCH 1, get the on/off state of output 1.

RESET command: to reset to factory default configuration.

REBOOT command: to reset the PDU

## 7. Technical parameters

No	Item		Parameters
1	Input	Rated input voltage	110/220V~ 0/60 Hz

		Input plug	Standard: IEC60309 plug
		Cable	16A: 3×2.5mm <sup>2</sup> , 32A: 3×6.0mm <sup>2</sup>
		Max. load	16A, 32A
		Overload protection	Master circuit breaker 1P
2	Output	Rated output voltage	110/220VAC
		Max. load	16A, 32A
		Outlet types	Standard: IEC320 C13 Other sockets optional
		Outlet numbers	Optional
3	Ports	NET port	1 x RJ45
		Serial port	1 x RJ45
		Temperature/humidity sensor port	1 x RJ11
4	Display	Operation state	1 x LED
		Error state	1 x LED
5	Digital ammeter	Total ampere	Full scale: 32A/16A Accuracy: ±1 % + 0.2 Resolution: 200mA; Response: 400ms
		Individual ampere	Full scale: 25A Accuracy: ±1 % + 0.1 Resolution: 100mA ; Response: 400ms
6	Temperature		Working condition: -40°C~+100°C, Accuracy: ±1°C; Response: 4s
	Humidity		Accuracy: ±5 % RH Response: 400ms
7	Dimension	L×W ×H	X <sup>2</sup> ×66.6×44.4mm
8	Case	Color	Black
9	Fittings	Mounting brackets	2pcs
		Ethernet wire	2M, blue

		Serial wire	2M, yellow
		User Manual	1 x CD
10	Optional fitting	Sensor	Temperature & humidity sensor
11	Environment	Working condition	0°C~55°C
		Relative humidity	10~90%
		Storage	-20°C ~ +70°C
12	ROHS	YES	

## 8. Quality Warranty

The PDU warrants to be free for repairing in two years from the date of purchasing. During this period, our obligation is limited to repair, replace or return to our company for repair. If the product has been beyond the warrant for repairing time or it has been damaged by accident, negligence or misapplication, you should pay some repair charge.

The above warranty does not apply to the following situation:

1. The damage caused by customers' incorrect or inadequate repair;
2. The damage caused by unauthorized modification or misusing;
3. The damage caused by using out of the product allowed environment.

Repairing Notice:

1. If you want to return the product for repair, please make sure it packed in the bandbox or carton.

The damage caused during the transportation is not warranted to repair.

2. Please give a brief description of the repairing product about the problem and its operating process.
3. The customer should pay for the returning freight, all the tariffs and taxes.
4. Please write down your name, address and the telephone number by which we can contact you at anytime.